



1、Login the camera IE—Configuration—Alarm input—Link Type, then choose Sound from the drop-down list




If you do not see the choice, find it in next picture.


Log in the camera IE—Configuration—VCA Schedule—Link Type, then choose Sound




2、 Choose customized1 from the “Warning voice” drop-down list









3、 Click the download button



4、 Set up the software









How to use the software “AudioMaker”?




1、 Open the software in which you can set the language in English





2. Click the button begin to record sound, then talk by microphone




3、Click again to stop record sound



4、Start packing



4、 You can find the update file



5、 Log in IE, click upgrade button to update this file.

The screenshot displays a web interface with a green navigation bar at the top containing 'Live View', 'Playback', 'Log', and 'Configuration'. The 'Configuration' tab is selected and highlighted with a red box. On the left, a sidebar menu lists various settings, with 'System Maintenance' highlighted in blue and enclosed in a red box. The main content area is titled 'System Maintenance' and is divided into several sections: 'Device Control' with buttons for 'Basic Recovery', 'Comple...covery', 'Reboot', 'Lens Reset', and 'Open re..service'; 'Configuration In/Out' with an 'Import' field (filter: (\*.box)) and 'Browse'/'Import' buttons, and an 'Export' button; 'Firmware Upgrade' with an 'Upgrade File' field (filter: (\*.bin)or(\*.box)) and 'Browse'/'Upgrade' buttons, all enclosed in a red box; and 'Auto Maintenance' with a 'Restart Time' dropdown menu set to 'Never'.