




1. Enter Device Management.




2. Click More-Configuration.



3. Choose System settings.



4. After choosing Time zone, click Synchronize time zone.



5. On the preview interface, the time of the channel will be changed.

