


How can Android mobile receive mobile alarm?


1. Open EasyLive, choose “Local Configuration”.




2. Enable “Received alarm locally” and “Download alarm pictures automatically”.




3. Open main menu, enter “Device Management”.




4. Choose "More-Conf".



5. Enable “Enable alarm push”, and then click “Enable channel alarm”.



6. Enable “Mobile alarm”.



7. The camera should have SD card, and EasyLive can receive the picture.

8. How does Android phone itself set software notification permissions?

8.1 Enter setting -- Notifications & status bar.

8:49

4G

Settings

- Display >
- Wallpaper >
- Themes >
- Sound & vibration >

SYSTEM & DEVICE

- Lock screen & password >
- Notifications & status bar >
- Home screen & Recents >
- Full screen display >
- Mi AI >
- Second space >

8.2 Choose App notifications.

8:48

4G

Notifications & status bar

Notifications folder All unimportant notifications will appear in a separate folder

App notifications >

STATUS BAR

Show notification icons

Show connection speed

Show carrier when device is locked

8.3 Choose EasyLive.

8:48

4G



App notifications

-  **Contacts and dialer**
Badges >
-  **Cortana**
Badges >
-  **Dianping**
Badges >
-  **Downloads**
Badges >
-  **EasyLive**
Badges, Floating notifications >
-  **Feedback**
Badges >
-  **File Manager**
Badges >

8.4 Set notification, voice, and other related permissions.

8:48

4G




EasyLive


- Show notifications**
- Mark as important? Important >
- App icon badge
- Floating notifications
Allow important notifications at top of the screen
- Lock screen notifications
Allow important notifications on the Lock screen
- Sound**
- Vibration**
- Notification light

How can iphone receive mobile alarm?


1. Open Easylive, choose “Local Configuration”.




2. Enable “Received alarm locally” and “Download alarm pictures automatically”.




3. Open main menu, enter “Device Management”.




4. Choose "More-Conf".



5. Enable "Enable alarm push", and then click "Enable channel alarm".




6. Enable “Mobile alarm”.




7.The camera must have SD card and set link picture, and EasyLive can receive the picture.

8. How does iphone itself set software notification permissions?

8.1 Enter setting—EasyLive.



8.2 Choose Notifications.



8.3 Set notification, voice, and other related permissions.

EasyLive Notifications

Allow Notifications

Sounds


Badge App Icon

ALERTS


Show on Lock Screen

Show in History

Show as Banners



Temporary



Persistent

Temporary banners appear at the top of the screen and go away automatically.

OPTIONS

Common problems

1. EasyLive can receive the alarm, but did not snap pictures?

1.1 The camera must have a storage device SD card.


1.2 Set up linkage snapshots in mobile alarm.

The screenshot displays the Tiandy web interface for configuring Motion Alarm. The interface includes a navigation menu on the left, a main content area with a camera feed, and a configuration panel on the right.

- Navigation Menu:** Audio Video Set, Dome Set, VCA, OSD, Storage Management, Network Management, User Management, Alarm Management (Alarm Input, Alarm output, **Motion Alarm**, Mask Alarm, Email Alarm, Other Alarms, Alarm Server), PTZ Management, Advance Set.
- Main Content Area:** Titled "Motion Alarm", it shows a camera feed with a red grid overlay. A "Delete Region" button is located below the feed.
- Configuration Panel:**
 - Enable
 - Sensitivity: 76
 - Schedule: Friday
 - Time slots: 00:00 ~ 23:59, 00:00 ~ 00:00, 00:00 ~ 00:00, 00:00 ~ 00:00
 - Copy To: All, Sun, Mon, Tue, Wed, Thu, Fri, Sat
 - Link Type: Link Snap
 - Channel No.: All
 - 1
 - Save

2. How does iphone allow EasyLive to be allowed to use data?

2.1 Enter setting, and choose EasyLive.



2.2 Enter “Wireless Data”, open “WLAN&Cellular Data”.

中国移动 4G

4:23 PM

85%

< Settings

EasyLive

ALLOW EASYLIVE TO ACCESS



Photos

Add Photos Only >



Microphone



Camera



Siri & Search

Search & Siri Suggestions



Notifications

Badges, Sounds, Banners



Wireless Data

WLAN & Cellular



中国移动 4G

4:24 PM

85%

< EasyLive

EasyLive

ALLOW "EASYLIVE" TO USE DATA

Off

WLAN

WLAN & Cellular Data

